

**Typical range of power consumption (Wattage)
of some of the commonly used appliances**

Appliances	Wattage (Range)
Aquarium	50-1210 Watts
Clock radio	10
Coffee maker	900-1200
Clothes washer	350-500
Clothes dryer	1800-5000
Dishwasher	1200 -2400 (using the drying feature greatly increases energy consumption)
Dehumidifier	785
Electric blanket- Single/Double	60 / 100
Fans	
Ceiling	65-175
Window	55-250
Furnace	750
Whole house	240-750
Hair dryer	1200-1875
Heater (portable)	750-1500
Clothes Iron	1000-1800
Microwave oven	750-1100
Personal Computer	
CPU - awake / asleep	120 / 30 or less
Monitor - awake / asleep	150 / 30 or less
Laptop	50
Radio (stereo)	70-400
Refrigerator (frost-free, 16 cubic feet)	725
Televisions (color)	
19"	65-110
27"	113
36"	133
53"-61" Projection	170
Flat Screen	120
Toaster	800-1400
Toaster Oven	1225
VCR/DVD	17-21 /20-25
Vacuum cleaner	1000-1440
Water heater (40 gallon)	4500-5500
Water pump (deep well)	250-1100
Water bed (w/ heater, no cover)	120-380